



SDK1 Safe Deposit Killer Kit

Your SDK1 kit includes the following items:

- 5/8" Hole Saw
- 3/4" Hole Saw
- Arbor
- A Guide for Diebold and others (used with 3/4" hole saw)
- B Guide for S & G 4400 (used with 5/8" hole saw)
- C Guide for S & G 4442 (used with 3/4" hole saw)

COVERAGE

A Guide (Use with 3/4" Hole Saw)

Diebold 175 series 175-05, 175-06, 175-70, 175-15, 175-90

B Guide (Use with 5/8" Hole Saw)

S&G 4400 series 4231, 4431, 4440, 4444, 4420

S&G 4500 series 4544, 4545, 4555, 4564, 4565

S&G 4100 series 4110, 4111, 4112, 4113

Ilco A series

Lloyd Matheson S&G clones

Lefebure S&G clones

Guardian 6832

Bullseye S&G clones

C Guide (Use with 3/4" Hole Saw)

Large guide with S&G size keyway adapter

S&G 4442, 4443

These guides will remove the renter plug for multiple brands/models in seconds. This is only a sample. They will basically remove the plug from any lock that the guide will slide into. It will also remove guard plug from most models and works with left of right-hand locks.

INSTRUCTIONS FOR USE

Slide the appropriate guide into the lock by inserting it flag-end first (see image below). Use the correct size hole saw in your drill set to lowest speed. Drill enough to remove a portion of face cap that holds plug, usually less than 1/8" deep. Remove the hole saw and guide from the lock. It is important to remove the guide at this point to prevent damage to the tool. Use a small screwdriver or hook to pull the plug from lock. The foot will also need to be removed. It is optional to continue drilling the face cap deep enough to allow easier removal of the foot. Stop drilling before the hole saw comes in contact with the levers. After the plug and foot are removed turn the guard key and use a hook pick to move bolt to the unlocked position. Some changeable doors like Guardian will need to be pulled like a regular lock once the plug is removed.

DIEBOLD INSTRUCTIONS

Install the guide into the lock and use the large hole saw in your drill set to lowest speed. Drill approximately 1/8" into the face cap. Remove the hole saw and guide. Carefully continue drilling thru face cap with the hole saw until it is deep enough to release the plug. Care must be taken to keep hole saw centered and straight. Original Diebold solid brass plugs will need to be pulled out far enough to grip. Pull the plug until the foot is dislodged. Original Diebold and clone aluminum one piece plug/foot will snap easily. Remove foot and turn the guard key. Use a hook pick to slide bolt to unlock.



If you have any questions please feel free to contact us.

Framon Manufacturing Company, Inc
1201 W Chisholm St
Alpena MI 49707
Phone: 989-354-5623
Web: www.framon.com / www.bluedogkeys.com
E-mail: sales@framon.com

Please keep us in mind when you need key cutting equipment (like the DBM-1 for safety deposit box keys) or key blanks (visit www.bluedogkeys.com)!